



## CHEVROLET, FORD AND DODGE HEADLINER MOUNT INSTALLATION AND USER GUIDE

| Description  | Part Number  |
|--|--------------|
| CHEVROLET, FORD AND DODGE HEADLINER MOUNT FOR WHELEN CENCOM                  | AS4.C244.006 |
| CHEVROLET, FORD AND DODGE HEADLINER MOUNT FOR SOUND OFF BLUEPRINT 500 SERIES | AS4.C244.014 |

### Product Mounting Disclaimer

Precision Mounting Technologies Ltd (PMT) are not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use PMT products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brake lines, electrical, drive train or other systems), air-bags and other safety equipment is required. PMT specifically disclaims any responsibility for the improper use or installation of its products not consistent with original vehicle manufactures' specifications and recommendations, PMT product instruction sheets, or workmanship standards as endorsed through PMT policies and EULA.



# PRODUCT VISUALS



# INSTALLATION INSTRUCTIONS

## Step 1

OEM headliner prior to install



## Step 2

Gently use prying tools to OEM headliner, and remove the "T" shape cover



## Step 3

Use T-15 Torx screwdriver to remove 2x T-15 screws in the front and pry two clips in the back



# INSTALLATION INSTRUCTIONS

## Step 4

Put the back plate in place, and drill four 0.20" DIA on the roof accordingly. (1.6" apart)



## Step 5

Put the headliner mount in place, and use #10-24x5/8 screws from the hardware bag to attach it



## Step 6

Put the OEM cover back

